



# 自动加油曲折缝

AUTO-OIL FILLED ZIGZAG SEWING MACHINE

## 使用说明书

OPERATION MANUAL

## 零件样本

PARTS BOOK

中国·中捷缝纫机股份有限公司  
ZOJE SEWING MACHINE CO., LTD.

# 目 录

一、用途.....	1
二、安全操作事项.....	1
三、操作前的注意事项.....	1
四、机器的润滑.....	1
五、针线的选用.....	2
六、机针的安装.....	2
七、换梭心套.....	2
八、绕梭心线.....	2
九、梭心的安装.....	3
十、穿面线.....	3
十一、线迹长度的调节.....	4
十二、压脚压力的调节.....	4
十三、面线张力的调节.....	4
十四、挑线簧张力及行程的调节.....	5
十五、底线张力调节.....	5
十六、针位的调节.....	5
十七、横针距(即摆针宽度)的调节.....	6
十八、机头部分油量的调节.....	6
十九、皮带罩的安装.....	6
二十、膝控部件的安装.....	7
二十一、几种缝纫方法和附件的使用.....	7
二十二、机器的维护.....	9
二十三、主要技术规格.....	9



# CONTENTS

1. Application.....	1
2. Secure operation.....	1
3. Caution before operation.....	1
4. Lubrication.....	1
5. Selection of needle and thread.....	2
6. Inserting of needle.....	2
7. Replacing bobbin.....	2
8. Thread the bobbin case.....	2
9. The installation of the bobbin.....	3
10. Thread surface stitches.....	3
11. Adjusting stitch length.....	4
12. Adjusting presser foot pressure.....	4
13. Adjusting needle thread tension.....	4
14. Regulate the length and tension of take-up spring.....	5
15. Adjust bobbin thread tension.....	5
16. Adjust needle position.....	5
17. The adjustment of horizontal distance.....	6
18. To mount thread unwinder.....	6
19. Assemblage of belt cover.....	6
20. Mount knee lifter.....	7
21. Modes of several sewing stitch and application of accessory.....	7
22. Maintain of machine.....	9
23. Main specification.....	9

## 一、用途

### 1. APPLICATION

该机广泛用作服装、床上用品、鞋帮、毛巾、壁毯等的薄、中、厚料曲折缝、曲折刺绣缝或直缝。

采用了高精度的机械传动和有效的膝控摆幅部件，确保了形成多种线缝的完美质量。

This series of zigzag sewing machine is used to zigzag, embroidery and lockstitch on thin, medium and thick material for garment, bed articles, shoes, towels and wall carpet.

Extra accurate mechanical transmission and knee-control swing range unit assure many kinds of perfect embroidery stitch.

## 二、安全操作事项

### 2. SECURE OPERATION

1. 操作人员须经适当培训并仔细阅读该使用说明书后，方可使用；

2. 使用机器时，安全装置必须安装齐全；

3. 当拆换机器部件（如：机针、压脚、针板、送料牙和梭心等）、穿线、岗位上无操作人员或维修工时，必须关闭电源开关或拔下电源插头；

4. 机器的维修、调整等工作必须由专业技术人员进行；

5. 电气设备的使用必须由电工或专业技术人员进行。

1) The operator should be trained, and understand this manual very well before operating.

2) All security equipments should be fixed very well while running the machine.

3) Turn off the power or draw the power off, while unfixing accessories (like needle, presser foot, needle plate, feed dog and bobbin case), winding thread and no operator is at the workplace maintaining the machine.

4) Maintenance and adjustment of the machine should be carried by professional technician.

5) The electricity equipment should be managed by wireman or professional technician.

## 三、操作前的注意事项

### 3. CAUTION BEFORE OPERATION

为避免机器损坏，必须彻底注意下列事项：

1. 首次使用机器时，必须彻底清洗、充分加油；

2. 检查电机电压是否正常，连接相位是否正常；

3. 上轮一定要朝操作者方向运转。

To avoid the damage of machine, don't care of the following:

1) Please clean the machine thoroughly, add enough oil before first usage.

2) Check the normalcy of voltage connecting oil before first usage.

3) The upper wheel should rotate in the direction facing the operator.

## 四、机器的润滑(图 1、2)

### 4. LUBRICATION (Fig. 1, 2)

1. 翻开机头，向油盘注入缝纫机油至 HIGH 记号部位(图 1)。

2. 当油面低于 ADD OIL 记号时，应再加新油(图 1)。

3. 加油后，开动机器，应看到油液连续飞溅到油窗 A，说明润滑正常(图 3)。

4. 所用的油在 38℃ 时，粘度为 20.0mm/s，在 15℃ 时，浓度为 0.888g/m，建议使用 18 号油。

1). Turn Over the machine head, Pour the oil into the oil pan to the "HIGH" marks.



2). While the oil is lower than "ADD OIL", please pour the new oil into the oil pan.

3). Turn on the machine after pouring oil, if the oil splash on the oil window A. frequently, the lubrication is good order.

4). The viscosity the used oil of should be 20.00mm/s when the oil temperature is 38℃.

The density of the used oil should be 0.888g/m when the oil temperature is 15℃.

We suggest that you should use No. 18 white oil.





## 五、针线的选用

### 5. SELECTION OF NEEDLE AND THREAD

根据不同缝料, 应选用相应合适的机针及缝线, 推荐参阅表 1:

表 1

适用类型	薄料	中厚料	厚料
最粗针线	120	60	30
机针大于 (1/100mm)	#10	#12-#16 (80-100)	#18-#19 (110-120)
机针类型	1910-05(135x9)		
可用其他类型相当的针线			

Select the appropriate thread and needle according to the different sewing material as following:

Applicable kind of material	Thin	Medium heavy material	Heavy material
Max size of thread	120	60	30
Needle size (1/100mm)	#10	#12-#16 (80-100)	#18-#19 (110-120)
Needle type	1910-05(135x9)		
Other equal suitable size thread usable.			

## 六、机针的安装(图 3)

### 6. INSERTING OF NEEDLE(Fig.3)




图 Fig.3

盘动上轮使针杆上升到最高位置, 松开机针紧固螺钉 1, 将机针柄插到顶, 长槽面向操作者, 然后, 拧紧紧固螺钉 1。

Turning the hand wheel and raise the needle bar to the highest position, then loose the needle rightening screw 1. Insert the needle in the needle bar and push it up as far as it will go.

Make sure its long groove faces toward the front. Tighten needle set screw 1 securely.

## 七、换梭心套(图 4、图 5)

### 7.REPLACING BOBBIN CASE (Fig.4,5)




图 Fig.4




图 Fig.5

抬起梭门盖 1, 即可取出梭心套 2。

装上梭心套时, 要求先拉开梭门盖 1, 将梭心套插入梭床芯轴 2 上。使梭心套梭门 3 与梭床定位槽 4 相扣合, 然后放下梭门盖, 紧压在梭床上, 再合上推板。

Raise latch 1, then pick out the bobbin case 2.

Open bed slide 1 and lay the case on the case shaft 2, while the case hook 3 fit location channel 4, then down the bed slide and press the case and push the plate.

## 八、绕旋心线

### 8. THREAD THE BOBBIN CASE

1. 左手抓住上轮, 右手将离合器螺钉①朝 A 方向转动松开。

2. 将梭心套入绕线器轴③, 尽可能地按下, 预调上夹线⑥的张力, 上夹线螺母超 + 方向转动时, 张力将增大, 朝 - 方向转动时, 张力将减小。

3. 按箭头 C 方向推上绕线量调节压板②, 然后起动机绕线, 梭心将按 B 方向旋转。欲调节梭心上的绕线量, 先旋松调节压板螺钉④, 向操作者方向转动调节

压板, 绕线量将减少, 反之, 绕线量将增加。调整后, 旋紧调节压板螺钉。

4. 如果绕线不均匀, 旋松螺钉⑤, 上下移动上夹线⑦使绕线均匀, 然后旋紧螺钉⑥。

1). Stop motion of needle by loosening stop-motion screw (1). Hold hand wheel with left hand and turn stop-motion screw toward you with right hand.

2). Place bobbin on bobbin winder spindle (3), pushing it on as far as it will go.

Pre-tension (1)

+.....More tension.

-.....Less tension.

3). Push latch (2) in the direction indicated by arrow (A), then start the machine.

Bobbin winder spindle (3) rotates in the direction indicated by arrow (B).

To adjust the amount of thread on bobbin, loosen screw (4) on latch (2) and swing the latch (2) and swing the latch (2) away from you or toward you, as required.

4). For more thread on bobbin, swing latch (2) away from you.

For less thread on bobbin, swing latch (2) toward you, if thread winds unevenly on bobbin, loosen screw (5) and move pre-tension (6) up or down, as required, and tighten screw (5).




图 Fig.6

#### 九、梭心的安装(图 7、8、9、10)

#### 9. THE INSTALLATION OF THE BOBBIN (Fig.7,8,9,10)




图 Fig.7




图 Fig.8




图 Fig.9




图 Fig.10

1. 梭心装入梭心套 (图 7), 将线从长槽 2 及梭皮 1 拉出(图 8)

2. 将线拉出梭皮末端和孔 2 (图 9)

3. 把线穿过过线孔 1, 留出 60 毫米长的线头 (图 10)。

1). Put the bobbin into bobbin case. Pull thread into notch 1 and draw it under tension spring 2. (Fig.7)

2). Draw thread out from slot 2 on end of spring 1.(Fig.9)

3). Pass it through bobbin case thread guide (1), allow about 60mm of thread out of the bobbin. (Fig.10)

#### 十、穿面线(图 11、12、13、14)

#### 10. THREAD SURFACE STITCHES (Fig.11,12,13,14)




图 Fig.11






图 Fig.12




图 Fig.13




图 Fig.14

1. 针杆调到最高位置, 然后从线架上引出线头, 依次穿过 A、B、C、D、E 和 F。

2. 如图 14 由前向后穿线。

3. 引出长 100 毫米左右的线头。

1). Raise needle bar to the highest position, then pull the thread out and through A, B, C, D, E and F.

2). As Fig.14, thread from forward to back.

3). Pull about 100mm of thread out.

## 十一、线迹长度的调节(图 15)

### 11. ADJUSTING STITCH LENGTH (Fig.15)

(1) 直线缝线迹长度 (即针距) 调节




图 Fig.15

按顺时针或逆时针方向旋转针距旋钮 1。

+.....针距变长;

-.....针距变短。

(2) 倒顺送料的调节

当倒顺扳手 2 处于自由状态时, 机器处于顺进料的状态。

当按下倒顺扳手 2, 机器处于倒送料状态。

按顺时针或逆时针方向旋转止旋螺钉 3, 可调节倒送料的针距长度。

+.....针距变长;

-.....针距变短。

## Regulating the stitch length

To regulate the stitch length, turn feed regulating dial 1 toward left right as required,

+.....to lengthen

-.....to shorten

## Changing the reverse feed

Push lever 2, release for forward feed and down for reverse feed.

To regulate the reverse stitch length, turn thumb screw 3 toward left or right as required.

+.....to lengthen

-.....to shorten

## 十二、压脚压力的调节(见图 16)

### 12. ADJUSTING PRESSER FOOT PRESSURE (Fig.16)

顺时针旋转调压螺钉 1, 压力增大。

逆时针旋转调压螺钉 1, 压力减小。

To regulate the presser foot pressure, turn pressure regulating screw 1, toward left to strengthen or right to reduce pressure.




图 Fig.16

## 十三、面线张力的调节(图 17)

### 13. ADJUSTING NEEDLE THREAD TENSION (Fig.17)

顺时针旋转夹线螺母 1, 张力增大。

逆时针旋转夹线螺母 1, 张力减小。

+.....张力增大

-.....张力减小

Regulate needle thread tendion with tension regulating knob 1. toward left to strengthen or right to r3educe pressure.

+.....more tension

-.....less tendion




图 Fig.17

#### 十四、挑线簧张力及行程的调节 (图18)

#### 14. REGULATE THE LENGTH AND TENSION OF TAKE-UP SPRING (Fig.18)




图 Fig.18

##### 1、挑线簧张力的调节

用螺丝刀旋转夹线螺钉 1, 调节挑线簧的张力

+.....张力增大

-.....张力减小

##### 2、挑线簧行程的调节

用螺丝刀旋松夹线器紧定螺钉 2, 旋转夹线器组件

3, 调节挑线簧的位置合适, 再紧固螺钉 2。

##### 1). Regulate the tension of teke-up spring

Using a screwdriver in slot to regulate take-up spring tension by turning stud (1) as required.

+.....more tendion

-.....less tendion

##### 2). Regulate the length of take-up spring

To adjust the amount of take-up spring movement, loosen screw 2 and se take-up spring height by turning the entire tendion assembly 3 toward left or right. Then securely tighten screw 2.

#### 十五、底线张力的调节(图19)

#### 15. ADJUST BOBBIN THREAD TENDION (Fig.19)

松开螺钉 2, 旋转底线梭皮螺钉 1, 调节底线张力。

+.....张力增大

-.....张力减小

Regulate bobbin thread tension regulating screw 1.

+.....more tension

-.....less tension




图 Fig.19

#### 十六、针位的调节(图 20)

#### 16. AFJUST NEEDLE POSITION (Fig.20)

此类机器机针左、中、右位置的调节法, 直缝与曲折缝均相同。只要将左、中、右定位于手柄移至想要的位置, 即可缝出相应的线迹。

注意: 机针下有缝料时, 不可调整针位。

Left, Center and Right needle position settings are available for placement of both straight and zigzag stitching.(Fig20)

To position, push leverin and move to desired setting.

Do not make any needle position adjustment while the needle is in the fabric.




图 Fig.20

#### 十七、横针距(即摆针宽度)的调节 (图 21)

#### 17. THE ADJUSTMENT OF HORIZONTAL DISTANCE (Fig.21)






图 Fig.21

当需要调出曲折缝的横针距某一定值时，可按下列方法进行：

- (1) 松开摆针扳手定位螺钉 2;
- (2) 将横针扳手 3 扳至 0 位 (即 A 位置);
- (3) 锁紧摆针定位螺钉 2;
- (4) 松开摆针定位螺钉 1;
- (5) 顺时针旋转横杆扳手 3 至 B 位置;
- (6) 再锁紧摆针定位螺钉 1。

If one fixed value between the min-max of curvilinear stitch is needed, the adjustment can be made as follows:

- 1). Release the horizontal needle set screw 2;
- 2). Turn the spanner 3 to Oposition (i.e. A position);
- 3). Lock the set screw 2;
- 4). Release the needle set screw 1;
- 5). Turn left the spanner 3 to B position;
- 6). Then lock the set screw 1.

## 十八、机头部分油量的调节(图 22)

### 18. TO MOUNTTHREAD UNWINDER (Fig.22)

当需调节机头部分油量时，拿开象开塞 3(2 油量)，用螺丝刀拧动 A 处，以调节 1 的位置，当如图位置 A 油量很大，要使油量最小时，将转动 90 度。

While adjusting the oil amount of the machine head, please take out the rubber cap 3 ("2" is oil pipe). Turn A by screw driver to adjust the position of "1". While the position is shown in the oil amount is max. If you want to decrease the oil amount. Please turn "1" around 90°.




图 Fig.22

## 十九、皮带罩的安装(图 23)

### 19. ASSEMBLAGE OF BELT COVER (Fig.23)

台板上：使手轮 V 形皮带和皮带护罩成一直线，然后拧紧螺钉。

台板下：安装皮带罩后电机轮和皮带要旋转自如。

On the table: while the V type belt is line with belt cover, tighten the screw.

Under the table: after the assemblage of belt cover the wheel and belt should rotate freely.




图 Fig.23

## 二十、膝控部件的安装(图 24、)

### 20. MUNT KNEE LIFTER (Fig.24)

#### 1. 压脚膝控提时的调整

1) 向左抬起压脚扳手 ③，使压脚 ⑥ 处于抬起状态，调节油盘下膝控部件，使 ③ 与 ① 起作用，推动足膝控板，压脚的控制高度为 9 毫米。

#### 2. 横针膝控时的调整

1) 调节油盘下膝控部件，使 ④ 与 ② 起作用，旋松横针调节板螺钉 ⑦、⑧，使用至膝控部件到顶端，横针距达到最大值。

#### (1) To adjust presser lifter

Lift the presser foot ⑥ by presser lifter ③ and then adjust ③ and ① to push the knee lifter controller to the end, the lifting height is up to 9mm.

#### (2) To adjust width stitch

Adjust the knee lifter under the oil pan by ④ and ②, the loosen the adjusting screw ⑦、⑧、

Push the knee lifter controller to the end, the width stitch is up to Max.




图 Fig.24

## 二十一、几种缝纫方法和附件的使用

### 20. MODES OF SEVERAL SEWING STITCH AND APPLICATION OF ACCESSORY

(20U33/43/53/63)

#### 1. 直缝

采用专用的直缝压脚，针板与送料牙(图25)，比采用多功能压脚，针板与送料牙进行直缝，效果更佳。

进行直缝时，横针距必须调至0，采用直缝锁紧装置锁紧“针杆摆动架”，并换上专用压脚、针板、送料牙。

#### 1. Linear sewing

In case of linear sewing, using the linear swaying presser foot, needle and feeding dog is better than using multi-function ones.(Fig.25)

While do linear sewing, the horizontal width

should be adjust to 0 position, the linear locking unit with swaying rack of locking needle shaft can be used in combination with swaying rack of locking needle shaft can be used in combination with special presser foot, needle plate and material feeding tooth.




图 Fig.25

#### 2. 刺绣

#### 2.Embroidery

①必须使横针距在最小-最大之间任意调节，把直针距调至0位，并调整膝控部件(图24)，使膝部控制机针的摆动。

②卸下压脚、针板和送料牙，换上绣花板。

③用左手捏紧面线线头，用于朝自己方向转动上轮，使底线从针板孔中拉出。

④确保内外绷架将缝料绷紧，否则会引起跳针，断线及缝料皱缩。(图26)

#### Preparation before embroidery

1). It should be noted that any free regulation can be made at the horizontal needle distance between min-max, set the vertical needle distance to 0 position and will adjust the knee-control parts to make the component control the movement of the sway of needle.(Fig.24)

2). Discharge the presser for and needle plate and feeding dog, then change if with embroidering plate.

3). Hold firmly the end of the surface stitches with your left hand, turn the out from the holes of the needle plate.

4). To make sure to stretch tightly the material between the internal and external embroidering frames, otherwise, maybe cause skipping and stitches breaking or material creased.(Fig.26)






图 Fig.26

### 3. 拉链缝

#### 3. ZIPPERED SEWING

该缝法采用拉链压脚(图27),使于针迹接近突出的边,并旋松螺钉B,调节压脚,使机针位于压脚的左、右边槽A处,可适用于图28中几种情况。

This mode is preferable to make use of zippered presser foot (see Fig.32) in a bid to make the stitches more accessible to the projecting stitches, then release the screw B, regulate the presser foot and set the needle to the presser foot and set the needle to left and right grooves A of the presser foot. The mode is expected to suit for the following sewing.(Fig.37)




图 Fig.27




图 Fig.28

### 4. 卷边缝

#### 4. HEM-WRAPPING MODE

卷边缝采用卷边压脚(图29)

拆掉多功能压脚,换上卷边压脚,采用直缝法,针位选择中间,就可以进行图30的卷边缝。

In this mode, the hem-wrapping presser foot can be used as we wish (fig.29)

Remove the multi-functional presser foot and replace it with the hem-wrapping one. This is also a mode of linear sewing with the needle set to the central position; the hem-wrapping operation can be effected.(Fig.30)




图 Fig.29




图 Fig.30

### 5. 包梗缝

#### 5. STEM-WRAPPING MODE

进行包梗缝时,要换上专用的包梗压脚、针板、送料牙(图31),针位选择中间,横针距调节至3mm之内,把一条较粗的线绳穿过包梗压脚的水槽A,就可以进行包梗缝(图32)。

During the sewing with the stem-wrapping mode, the special stem-wrapping presser foot needle plate and material feeding tooth should be put into use(fig.31), the needle is set to the central position and the horizontal needle distance set to 3mm, and then run the rougher thread through the small groove A on the stem-wrapping presser foot so that the sewing of this mode will be smoothly conducted.,




图 Fig.31




图 Fig.32

#### 6. 装饰缝(图 33)

#### 6. DECORATION SEWING(Fig.33)

只要变换左、中、右的针位及熟练控制横针距,就可缝出如图 36 的图案。

If the left, central and right needle positions can be breeily changeable and the horizontal needle distance skillfully controlled, the patterns of the decoration sewing will be well achieved.




图 Fig.33

#### 7. 其他一些实用缝法(图 34)

#### 7. OTHER MODES OF PRACTICAL SEWING (Fig.34)

The machine should be cleaned periokically to remove lint and fluff, which may have accumulated around the working parts. A machine in continuous use should be oiled frequently.




图 Fig.34

表一- ENCLOSED FIGURE:

种类 Model	针迹类型 Stitch modes	最高缝速 Max.of speed	最大横针距 Max.horizontal needle distance	最大线迹长度 Length of stitches	膝控压脚提升高度 Height of lifter
ZJ20U93	W	2000 针 / 分 2000.r.p.m	9mm	5mm	9mm

## 二十二、机器的维护

### 22. MAINTAIN OF MACHINE

请爱护你的生产设备,务必每天尽一次清理,除去压脚、针板、送料牙和旋梭上的多余缝屑、灰尘,经常给机器清洁、润滑。

You should frotect your machine, and clean it every day. Remove lint and fluff which may hace accumulated around the working parts like presser foot, needle plate, feed dog and rotating hook. A machine in continuous use should be oiled and cleaned frequently.

## 二十三、主要技术规格

### 23. MAIN SPECIFICATION

针迹类型: 见附录

机器种类: 见附录

机针规格: 见表 1

手提压脚提升高度: 6.35mm

上轮: V 型带轮 74mm

工作空间宽度: 211mm(20U143:289mm)

工作空间高度: 130mm

最大针距: 见附录

最高缝速度: 见附录

The mode of stitches:see the enclosed

The mode of machine:see the enclosed

The specification of needle:see upper figure

The height of hand lifter presser foot:6.35mm

Upper wheel:model V belt wheel 74mm

The height of work:130mm

The max of needle distance:see the enchlosed

The highest sewing speed:see the enclosed



Sales Order

DATE	2014
TIME	10:00



SHIMADZU CORPORATION  
 1-1-1, HIRAKAWA-CHO, SUIT 101, KAWASAKI-KU, TOKYO 144-0292, JAPAN  
 TEL: 044-251-1111 FAX: 044-251-1112  
 E-MAIL: SALES@SHIMADZU.COM

ITEM	QTY	UNIT	PRICE	TOTAL
1	1	EA	10000	10000
2	1	EA	20000	20000
3	1	EA	30000	30000
4	1	EA	40000	40000
5	1	EA	50000	50000
6	1	EA	60000	60000
7	1	EA	70000	70000
8	1	EA	80000	80000
9	1	EA	90000	90000
10	1	EA	100000	100000


ITEM	QTY	UNIT	PRICE	TOTAL
11	1	EA	110000	110000
12	1	EA	120000	120000
13	1	EA	130000	130000
14	1	EA	140000	140000
15	1	EA	150000	150000
16	1	EA	160000	160000
17	1	EA	170000	170000
18	1	EA	180000	180000
19	1	EA	190000	190000
20	1	EA	200000	200000

# 零件手册 PARTS LIST

ITEM	QTY	UNIT	PRICE	TOTAL
1	1	EA	10000	10000
2	1	EA	20000	20000
3	1	EA	30000	30000
4	1	EA	40000	40000
5	1	EA	50000	50000
6	1	EA	60000	60000
7	1	EA	70000	70000
8	1	EA	80000	80000
9	1	EA	90000	90000
10	1	EA	100000	100000
11	1	EA	110000	110000
12	1	EA	120000	120000
13	1	EA	130000	130000
14	1	EA	140000	140000
15	1	EA	150000	150000
16	1	EA	160000	160000
17	1	EA	170000	170000
18	1	EA	180000	180000
19	1	EA	190000	190000
20	1	EA	200000	200000

Subtotal	2000000
Sales Tax (10%)	200000
Total	2200000


# FACE PLATE, ARM TOP COVER, ARM SIDE COVER



序号 NO.	型号 PART NO.	数量 QTY	名 称	DESCRIPTION
1	GK191-8	1	挑线杆防护罩	Thread take-up guard
2	GS378-8	1	挑线杆防护罩螺钉	Thread take-up guard screw
3	GR406/3-8	1	面板	Face plate comp
4	GW242-8	1	线勾	Face plate thread guide
5	GS374-8	1	线勾螺钉	Face plate thread guide screw
6	GS375-8	6	面板螺钉	Face plate screw
7	GK160-8	1	后盖板	Arm side cover
8	GS132-8	6	后盖板垫片	Arm side cover set screw
9	GK187-8	1	上盖	Arm top cover comp
10	GO206-8	1	拉簧销钉	Bobbim winder bracket spacer
11	GR780/9-8	1	绕线蕊轴细件	Bbabin winder bracket comp.
12	GW172-8	1	绕线蕊轴	Bobbin winder friction wheel spring
13	GO284-8	1	橡胶圈	Bobbin winder friction o-ring
14	GR375-8	1	绕线摆柄	Bobbin winder bracket regulating plate
15	GW173-8	1	绕线摆柄压簧	Bobbin winder bracket regulating plate spring
16	GW174-8	1	绕线摆柄压簧	Bobbin winder bracket spring
17	GX218-8	1	绕线曲柄销	Bobbin winder bracket hinge stud
18	GX182-8	1	绕线曲柄销螺钉	Bobbin winder bracket hinge set screw
19	GR726-8	1	线量调节压板	Bobbin winder lever comp.
20	GS378-8	1	线量调节压板螺钉	Bobbin winder lever set screw
21	GZ246-8	1	线量调节轴	Bbabin winder lecer stud
22	GO218-8	1	线量调节轴挡圈	Bobbin winder lever stud ring
23	GR481/2-8	1	绕线尾位块	Bobbin winder regulating comp.
24	GS222-8	1	绕线尾位块挡圈	Bobbin winder regulating screw
25	GR778/6-8	1	上夹线器	Bobbin winder tension comp.
26	GR234/5-8	1	上过线板组件	Bobbin winder tension stud comp.
27	GW175-8	1	上夹线簧	Bobbin winder tension spring
28	GR375-8	2	上夹线柄	Bobbin winder tension disc
29	GL175-8	1	上夹线螺母	Bobbin winder tension regulating thumb nut
30	GS275-8	1	上夹线器紧固螺钉	Bobbin winder tension set screw
31	GS680-8	6	上盖螺钉	Arm top cover screw
32	GK188-8	1	上盖垫片	Arm top cover packing
33	GK190-8	1	后盖板垫片	Arm side cover packing
34	GK186-8	1	面板垫片	Face plate packing



# THREAD TAKE-UP, ARM, HAND WHEEL




序号 NO.	型号 PART NO.	数量 QTY	名 称	DESCRIPTION
1	GR1431/12-8	1	挑线杆组件	Thread take-up comp.
2	GH200-8	1	挑线杆组件	Thread take-up lever with thrad eyelet bushing
3	GH143-8	1	挑线杆	Thread take-up lever thread eyelet bushing
4	GH141-8	1	挑线摇杆	Thread take-up lever link
5	GS166-8	1	倒牙螺钉	Needle bar connecting link cap screw
6	GH160-8	1	小连杆	Needle bar connecting link
7	GO511-8	1	上轴后轴套 O 形圈	Arm shaft(horizontal) flanged bushing(back) o-ring
8	GR1433/5-8	1	针杆连接轴体	Needle bar connecting stud comp.
9	GS160-8	1	针杆连接轴销紧定螺钉	Needle bar set screw
10	GS161-8	1	针杆连接轴销螺钉	Needle bar connecting stud hinge pin screw
11	GZ142-8	1	针杆连接轴销	Needle bar vonnecting stud hinge pin
12	GO141-8	1	针杆连接轴销垫圈	Needle bar connecting stud hinge pin washer
13	GH144-8	1	针杆曲柄	Thread take-up crank
14	GX144-8	1	挑线摇杆销	Thread take-up lever link hinge pin.
15	GS147-8	1	挑线摇杆销螺钉	Thread take-up lever link hinge pin set screw
16	GK254-8	1	小连杆导板	Needle bar connecting link guide
17	GS132-8	2	小连杆导板螺钉	Needle bar connecting link guide screw
18	GR1434/5-8	1	挑线曲柄组件	Arm shaft (horizontal) and needle bar crank comp.
19	GZ248-8	1	上轴	Arm shaft (horizontal)
20	GR1435/4-9	1	挑线曲柄	Needle bar crank comp.
21	GS168-8	1	挑线曲柄定位螺钉	Needle bar crank position screw
22	GS404-8	1	挑线曲柄紧定螺钉	Thread take-up crank position screw
23	GS404-8	1	挑线曲柄紧定螺钉	Thread take-up crank set screw
24	GS169-8	1	上轴前轴套螺钉	Arm shaft (horizontal)flanged bushing (front)set screw
25	GO143-8	1	上轴前轴套	Arm shaft (horizontal)flanged bushing (front)
26	GR1436/3-8	1	上轴弧齿锥齿轮	Arm shaft (horizontal)bevel gear comp.
27	GS167-8	2	上轴弧齿锥齿轮螺钉	Arm shaft (horizontal)bevel gear set screw
28	GR1437/3-8	1	上轴螺旋齿轮	Arm shaft (horizontal)worm gear comp.
29	GS170-8	2	上轴螺旋齿轮螺钉	Arm shaft (horizontal)worm gear set screw
30	GR1438-8	1	送布凸轮组件	Feed and feed lifting eccentric comp.
31	GS251-8	1	送布凸轮定位螺钉	Feed and feed lifting eccentric postion screw
32	GS251-8	1	送布凸轮紧定螺钉	Feed and feed lifting eccentric set set screw
33	GT153-8	1	送布凸轮	Feed and feed lifting eccentric ring
34	GS277-8	1	上轴后轴套螺钉	Arm shaft (horizontal) flanged bushing (back) set screw
35	GO510-8	1	上轴后轴套	Arm shaft (horizontal) flanged bushing (back)
36	GO209-8	1	上轮套筒	Clamp stop motion flanged bushing
37	GS380-8	1	上轮套螺钉	Clamp stop motion flanged gushing set screw
38	GE380-8	1	离合垫圈	Clamp stop motion clampo washer

序号 NO.	型号 PART NO.	数量 QTY	名 称	DESCRIPTION
39	GP151-8	1	离合螺钉	Clamp stop motion clamp screw
40	GR279-8	1	离合小螺钉	Clamp stop motion stop screw
41	GP142-8	1	上轮	Handwheel (for motor drive)




# NEEDLE BAR, PRESSER BAR, THROAT PLATE



序号 NO.	型号 PART NO.	数量 QTY	名 称	DESCRIPTION
1	GZ223-8	1	针杆	Needle bar (hollow)
2	GR485/5-8	1	针杆摆动架组件	Needle bar frame comp.
3	GR251-8	1	针杆摆动架	Needle bar frame
4	GR255-8	1	针杆定位片	Needle bar timing indicator plate
5	GS163-8	2	针杆定位片螺钉	Needle bar timing indicator plate screw
6	GS158-8	1	针杆紧定螺钉	Zigzag stitch regulator fork eccentric connection pin set screw
7	GS164-8	1	针杆摆动架销螺钉	Needle bar frame pin set screw
8	GX143-8	1	针杆摆动架	Needle bar frame pin
9	GR484/4-8	1	针夹组件	Needle clamp comp.
10	GR467-8	1	针夹	Needle clamp
11	GS290-8	1	线勾螺钉	Needle clamp thumb screw
12	GR466-8	1	针杆线勾	Needle clamp thread guard
13	GS289-8	1	机针紧定螺钉	Needle clamp thread guard set screw
15	GV130-8	1	机针	Needle (size#14)
16	GR1440/2-8	1	调压螺钉组件	Presser regulating thumb screw nut comp.
17	GS384-8	1	调压螺钉	Presser regulating thumb screw
18	GC178-8	2	调压螺母	Presser regulating thumb screw nut
19	GZ187-8	1	压紧杆	Presser bar
20	GW153-8	1	压杆簧	Presser bar Spring
21	GR1395-8	1	压杆导架	Presser bar guide Bracket comp.
22	GS232-8	1	压杆导架螺钉	Presser bar guide Bracket screw
23	GR1394-8	1	挺杆导架螺钉	Presser bar lifting and releasing lever bracket
24	GR465/4-8	1	挺线定位座	Presser foot (Spring Hinged) Comp.
25	GS231-8	1	压脚螺钉	Presser foot screw
26	GM156-8	1	针板	Throat plate
27	GS338-8	2	针板螺钉	Throat plate screw
28	GR477/4-8	1	针板内盖板组件	Bed plate comp.
29	GM130-8	1	针板内盖板	Bed plate
30	GW130-8	1	针板内盖板簧	Bed plate bracket
31	SG255-8	2	针板内盖板螺钉	Bed plate bracket screw
32	GR476/4-8	1	推板组件	Bed slide comp.
33	GM132-8	1	推板	Bed slide
34	GW131-8	1	推板簧	Bed slide spring
35	GM156-8	2	推板簧螺钉	Bed slide spring screw
36	GR1384-8	1	针杆摆动架毛毡	Needle bar frame oil felt


# ZIGZAG TRINGULAR CAM, HOOK ADVANCING CRANK



序号 NO.	型号 PART NO.	数量 QTY	名 称	DESCRIPTION
1	GS147-8	1	摆针轴螺钉	Zigzag triangulat cam shaft set screw
2	GR1441/2-8	1	摆针轴组件	Zigzag triangulat cam shaft comp.
3	GZ219-8	1	摆针轴	Zigzag triangular camp shaft
4	GZ221-8	1	摆针轴油线	Zigzag triangular camp shaft oil wick
5	GR145/6-8	1	摆针齿轮组件	Zigzag triangular camp shaft oil comp.
6	GR1442/3-8	1	摆针轴挡圈	Zigzag triangular cam shaft coller comp.
7	GS223-8	2	摆针轴挡圈螺钉	Zigzag triangular cam shaft coller set screw
8	GS132-8	1	小油盘螺钉	Oil reservoir set screw
9	GR1386-8	1	摆针轴 O 型圈	Zigzag triangulat camp shaft o-ring
10	GR1386-8	1	油窗	Oil gauge window
11	GR1390-8	1	小油盘上盖	Oil reservoir top cover
12	GR1387-8	1	小油盘组件	Oil Reservoir comp.
13	GR1391-8	1	小油盘油线	Oil reservoir oil wick
14	GK195-8	1	小油盘安装板	Oil reservoir plate
15	GS256-8	1	小油盘安装板螺钉	Oil reservoir plate set screw (back)
16	GS212-8	1	拉簧螺钉	Oil reservoir plate set screw (front)
17	GR288-8	1	横针拨叉	Zigzag stitch regulator fork
18	GX155-8	1	针杆偏心销	Zigzag stitch regulator fork eccentric connection pin
19	GS291-8	1	摆针滑块螺钉	Bight amplitude side block cap screw
20	GR978-8	1	油窗 O 形圈	Oil gauge window o-ring



# ZIGZAC TRIANGULAR CAM, HOOK ADVANCING CRANK




序号 NO.	型号 PART NO.	数量 QTY	名 称	DESCRIPTION
1	GS256-8	2	摆针针距定位块螺钉	Bight amplitude stop plate (left) (right) screw
2	GO174-8	2	摆针针距定位块垫圈	Bight amplitude stop plate (left) (right) washer
3	GR289-8	2	摆针针距定位块	Bight amplitude stop plate (left) (right)
4	GL153-8	2	摆针定位块调节螺母	Bight and L-C-R position lever arm regulating screw nut
5	GS215-8	2	摆针定位块调节螺钉	Bight and L-C-R position lever arm regulating screw
6	GS213-8	2	摆针针距定位架螺钉	Bight amplitude regulating plate holder set screw
7	GW142-8	1	摆针针距定位架拉簧	Bight amplitude regulating plate spring
8	GR290-8	1	摆针针距调节架(A)	Bight amplitude regulating plate (left)
9	GR291-8	1	摆针针距调节架(B)	Bight amplitude regulating plate (right)
10	GR294-8	1	摆针针距定位架	Bight amplitude regulating plate holder
11	GS383-8	2	摆针定位螺钉	Bight amplitude regulating plate thumb screw
12	GW141-8	1	摆针调节曲柄弹簧	Bight amplitude slide block crank spring
13	GR521-8	1	摆针定位组件	Bight amplitude slide block crank and guide comp.
14	GR519-8	1	摆针滑块组件	Bight amplitude slide block crank and slideblock
15	GO140-8	1	摆针滑块	Bight amplitude slide block
16	GR298-8	1	摆针导块座	Bight amplitude slide block crank guide comp.
17	GS185-8	1	摆针导块座螺钉	Bight amplitude slide block crank guides set screw
18	GR292/3-8	1	摆针调节曲柄组件	Bight amplitude slide block crank guide comp.
19	GS214-8	2	摆针调节曲柄螺钉	Bight amplitude slide block crank set screw
20	GH178-8	1	摆针调节连杆	Bight amplitude slide block crank link
21	GS216-8	2	差动连杆连接螺钉	Bight amplitude slide block crank link hinge screw
22	GR296-8	1	摆针定位块	Bight and L-C-R positing lever arm
23	GX154-8	1	摆针导块连接销	Bight amplitude slide block guide stud
24	GR1442/3-8	1	摆针板手定位挡圈	Bight amplitude slide block crank shaft bushing collar comp.
25	GR218-8	2	摆针板手定位挡圈螺钉	Bight amplitude slide block crank shaft bushing collar set screw
26	GO286-8	1	摆针板手轴套	Bight amplitude slide block crank shaft knob comp.
27	GR731-8	1	摆针板手	Bight amplitude slide block crank shaft bushing
28	GS278-8	2	单边曲折定位架螺钉	Bight amplitude L-C-R positing block set screw
29	GO217-8	2	单边曲折定位架垫圈	Bight amplitude L-C-R positing block washer
30	GR468-8	1	单边曲折定位架要	Bight amplitude L-C-R positing block
31	GS223-8	2	单边曲折调节架螺钉	Bight amplitude L-C-R positing lever set screw
32	GR1385-8	1	单边曲折调节架组件	Bight amplitude L-C-R positing lever comp.
33	GS281-8	1	单边曲折定位钉	Bight amplitude L-C-R positing lever screw pin
34	GL163-8	1	单边曲折定位钉螺母	Bight amplitude L-C-R positing lever screw pin nut
35	GS322-8	1	单边曲折扳手螺钉	Bight amplitude L-C-R positing lever thumb stud screw
36	GR621-8	1	单边曲折扳手轴 O 形圈	Bight amplitude L-C-R positing lever thumb stud washer
37	GR619-8	1	单边曲折扳手	Bight amplitude L-C-R positing lever thumb stud
38	GZ263-8	1	单边曲折扳手轴	Hand component shaft

序号 NO.	型号 PART NO.	数量 QTY	名 称	DESCRIPTION
39	GO512-8	1	单边曲折扳手轴套	Sleeve of homd component shaft
40	GO420-8	1	摆针扳手轴 O 形圈	O-ring of spanner of swaying needle




# ARM SHAFT (UPRIGHT), ROTATING HOOK DRIVE SHAFT



序号 NO.	型号 PART NO.	数量 QTY	名 称	DESCRIPTION
1	GR1444/3-8	1	立轴弧齿锥齿轮(上)	Arm shaft (upright) bevel gear (upper) comp.
2	GS199-8	2	立轴弧齿锥齿轮螺钉	Arm shaft (upright) bevel gear (upper) set screw.
3	GO228-8	1	立轴上轴套	Arm shaft (upright) bevel gear (upper)
4	GZ224-8	1	立轴	Arm shaft (upright)
5	GO229-8	1	立轴下轴套	Arm shaft (upright) bushing (lower)
6	GR1445/3-8	1	立轴弧齿锥齿轮(下)	Arm shaft (upright) bushing (lower) comp.
7	GS199-8	2	立轴弧齿锥齿轮螺钉	Arm shaft (upright) bushing (lower) set screw
8	GR1446/3-8	1	下轴弧齿锥齿轮(右)	Rotating hook drive shaft screw gear (back) comp.
9	GS199-8	2	下轴弧齿锥齿轮	Rotating hook drive shaft screw gear (back) set screw
10	GO231-8	1	下轴后轴套	Rotating hook drive shaft bushing (back)
11	GS147-8	1	下轴后轴套螺钉	Rotating hook drive shaft bushing (back) set screw
12	GR1447/3-8	2	下轴后轴套挡圈	Rotating hook drive shaft retainer collar comp.
13	GS199-8	4	下轴后轴套螺钉	Rotating hook drive shaft retainer collar set screw
14	GZ225-8	1	下轴	Rotating hook drive
15	G0162-8	1	油泵组件	Rotating hook drive shaft bushing (front)
16	GS147-8	1	油泵紧定螺钉	Rotating hook drive shaft bushing (front) setscrew
17	GR1448/3-8	1	下轴弧齿锥齿轮(轮左)	Rotating hook drive shaft bevel gear (front) comp.
18	GS199-8	2	下轴弧齿锥齿轮螺钉	Rotating hook drive shaft bevel gear (front) set screw
19	GZ168-8	1	动泵轴	Oil pump shaft
20	GZ269-8	1	油泵柱塞	Oil pump stopper
21	GW272-8	1	油泵柱塞弹簧	Oil pump stopper spring
22	GK196-8	1	油泵柱塞压板	Oil pump stopper pressural plate
23	GS687-8	2	油泵柱塞压板螺钉	Oil pump stopper pressural plate screw
24	GR1396-8	1	油泵筒管	Oil pump tube


# HOOK,BOBBIN CASE



序号 NO.	型号 PART NO.	数量 QTY	名 称	DESCRIPTION
1	GR1449/3-8	2	旋梭轴挡圈	Rotating hook shaft retainer collar comp.
2	GS202-8	4	旋梭挡圈螺钉	Rotating hook shaft retainer collar screw
3	GS201-8	1	旋梭轴轴套螺钉	Rotating hook shaft bushing (short) set screw
4	GO165-8	1	旋梭轴轴套	Rotating hook shaft bushing (short)
5	GR1450/3-8	1	旋梭轴弧齿锥齿轮	Rotating hook shaft bevel gear comp.
6	GS167-8	2	旋梭轴弧齿锥齿轮螺钉	Rotating hook shaft bevel gear set screw
7	GS201-8	1	旋梭轴前轴套螺钉	Rotating hook shaft bushing (long) set screw
8	GO163-8	1	旋梭轴前轴套	Rotating hook shaft gushing (long)
9	GZ164-8	1	旋梭轴	Rotating hook shaft
10	GK130-8	1	旋梭防护罩	Rotating hook shaft bevel gear cover
11	GS132-8	1	旋梭防护罩螺钉	Rotating hook shaft bevel gear cover screw
12	GN135-8	1	梭心	Rotating hook bobbin
13	GM131-8	1	旋梭	Rotating hook Rotating hook bobbin case hider comp.
14	GN135-8	1	梭子	Rotating hook bobbin case screw
15	GR278-8	1	旋梭定位板	Rotating hook bobbin case tension spring bracket
16	GS256-8	1	旋梭定位板螺钉	Rotating hook bobbin hider position bracket screw




# HOOK, BOBBIN CASE



序号 NO.	型号 PART NO.	数量 QTY	名 称	DESCRIPTION
1	GW167-8	1	针距定位钉压簧	Feed regulating stud lock pin sprign
2	GS685-8	1	针距定位钉	Feed regulating stud lock pin
3	GS684-8	1	针距调节螺杆	Feed regulating stud
4	GR738-8	1	针距旋钮	Feed regulating dial
5	GO380-8	1	针距旋钮螺钉垫圈	Feed regulating dial screw washer
6	GS387-8	1	针距旋钮螺钉	Feed regulating dial screw
7	GX302-8	1	针距座销	Feed regulating hinge stud
8	GR1452/2-8	1	牙叉组件	Feed forked connection comp.
9	GR1451/2-8	1	针距座	Feed regulating comp.
10	GS263-8	1	针距座螺钉	Feed regulating hinge stud set screw
11	GC142-8	2	小圆锥螺母	Feed connection link hinge scrw nut
12	GS188-8	2	送布曲柄螺钉	Feed connection link hinge screw
13	GH157-8	1	针距座连杆	Feed connection link
14	GR267-8	1	牙叉	Feed forked connection
15	GS188-8	1	小圆锥螺钉	Feed forked connection hinge screw
16	GC142-8	1	小圆锥螺母	Feed forked connection hinge screw nut
17	GR3412/2-8	1	倒针曲柄组件	Feed reverse lever link comp.
18	GS142-8	1	倒针曲柄螺钉	Feed reverse lever link screw
19	GW166-8	1	倒针复位拉簧	Feed reverse lever return spring
20	GR339-8	1	倒针复位拉簧钩	Feed reverse lever return spring bracket
21	GS256-8	1	倒针复位拉簧钩螺钉	Feed reverse lever lriturn spring bracket screw
22	GR735-8	1	倒针扳手组件	Feed reverse lever screw
23	GS1453/3-8	1	倒针调节螺钉	Feed reverse lever adjusting screw
24	GW200-8	1	倒针调节挡板	Feed reverse lever adjustiong scrw friction
25	GR737-8	2	倒针调节指示牌	Reverse feed indicator plate
26	GS42	1	倒针调节指示牌牌螺钉	Reverse feed indicator plate set screw
27	GR736-8	1	倒针调节挡板	Feed reverse liver adjusting screw stopper
28	GS386-8	1	倒针调节挡板螺钉	Feed reverse lever adjusting screw stopper set screw
29	GO514-8	1	针距座销 O 形圈	Feed reverse hinge stud o-ring
30	GR655-8	1	针距调节螺杆 O 形圈	Feed regnulating stud o-ring
31	GO514-8	1	倒针扳手轴 O 形圈	Feed reverse lever o-ring


# FEED REGULATING DIAL, FEED REVERSELEVER



序号 NO.	型号 PART NO.	数量 QTY	名 称	DESCRIPTION
1	GR504-8	1	抬牙连杆组件	Feed lifting rock shaft crank connecting rod comp.
2	GS142-8	2	抬牙连杆螺钉	Feed lifting rock shaft crank connecting rod cap screw
3	GR268-8	1	油毡	Feed lifting rock shaft crank connecting rod cap pad (felt)
4	GS188-8	1	小圆锥螺钉	Feed lifting rock shaft crank connecting rod hinge screw
5	GC142-8	1	小圆锥螺母	Feed lifting rock shaft crank connecting rod hinge screw nut
6	GR269-8	1	抬牙连杆组件	Feed lifting rock shaft comp.
7	GZ151-8	1	抬牙连杆	Feed lifting rock shaft roller and stud
8	GH1454/2-8	1	抬牙曲柄	Feed lifting rock shaft crank comp.
9	GS185-8	1	抬牙曲柄螺钉	Feed lifting rock shaft crank clamping screw
10	GR743-8	2	小圆锥螺钉	Feed lifting rock shaft screw center
11	GS263-8	2	小圆锥螺母	Feed lifting rock shaft screw center nut
12	GZ152-8	1	送由轴	Feed rock shaft
13	GR1455/2-8	1	送布曲柄	Feed rock shaft crank comp.
14	GS185-8	1	送布曲柄螺钉	Feed rock shaft crank clamping screw
15	GR265-8	1	牙架	Feed bar
16	GS183-8	2	牙架小顶尖螺钉	Feed bar screw center
17	GL140-8	2	牙架A 顶尖螺母	Feed bar screw center nut
18	GR774-8	2	小圆锥螺钉	Feed rock shaft screw center
19	GS263-8	2	小圆锥螺母	Feed rock shaft screw center nut
20	GS160-8	1	送料牙	Feed dog
21	GS184-8	2	送料牙螺钉	Feed dog screw
22	GK199-8	1	固定架	Holding yoke
23	GS690-8	2	固定架紧固螺钉	Holding yoke fastening screw
24	GW274-8	1	流珠弹簧	Roller spring
25	GO598-8	1	滚珠	Roller
26	GS688-8	1	滚珠螺钉	Roller screw
27	GR1400-8	1	吸油管	Oil suction pipe
28	GK198-8	1	滤油架	Splashing yoke of oil
29	GR1404-8	1	过滤罩	Filter sieve
30	GS687-8	1	滤油罩螺钉	Filter sieve screw




# PRESSER BAR LIFTER, TENSION



序号 NO.	型号 PART NO.	数量 QTY	名 称	DESCRIPTION
1	GR619-8	1	压脚扳手	Presser bar lifter
2	GT160-8	1	压脚扳手轴	Presser bar lifter cam stud
3	GR621-8	1	压脚扳手螺钉	Presser bar lifter screw
4	GK192-8	1	松线杠杆	Tension releasing lever
5	GW135-9	1	松线杠杆扭簧	Tension releasing lever spring
6	GS148-8	1	松线杠杆螺钉	Tension releasing lever hinge screw
7	GS379-8	1	双孔过线架	Thread retainer
8	GS139-7	1	双孔过线架螺钉	Thread retainer set screw
9	GR231-8	1	双过线架	Thread guard (upper)
10	GS223-8	1	双过线架螺钉	Thread guard (upper) set screw
11	GX180-8	1	过线柱	Thread guard pin
12	GR1456/11-8	1	夹线器组件	Tension comp.
13	GR237-8	2	夹线板	Tension disc
14	GR238-8	1	松线板	Tension releasing disc
15	GX132-8	1	松线钉	Tension releasing pin
16	GW208-8	1	夹线簧	Tension spring
17	GW131-78	1	挑线簧	Tension take-up spring
18	GR1457/2-8	1	挑线簧调节座	Tension take-up spring regulator comp.
19	GS147-8	1	夹线器紧定螺钉	Tension stud set screw
20	GS145-8	1	夹线螺钉	Tension stud
21	GL176-8	1	夹线螺母	Tension releasing thumb nut
22	GR239-8	1	制动板	Tension releasing thumb nut washer
23	GS146-8	1	夹线器螺钉架紧定螺钉	Tension take-up spring regulator screw
24	GZ204-8	1	抬压脚杠杆	Lifting lever
25	GS235-8	1	抬压脚杠杆螺钉	Lifting lever hinge screw
26	GR323-8	1	膝提压脚杠杆	Lifting lever connecting rod
27	GS184-8	2	开口销	Lifting lever connecting rod pin
28	GZ206-8	1	膝提供针杠杆	Bight amplitude slide block crank knee operating connection
29	GR621-8	1	压脚扳手轴 O 形圈	Presser bar lifter cam stud o-ring
30	GR328/10-8	1	膝提杠杆座	Bell crank comp.
31	GS683-8	2	膝提杠杆座螺钉	Bell crank bracket screw

# ACCESSORIES AND ATTACHMENT




序号 NO.	型号 PART NO.	数量 QTY	名 称	DESCRIPTION
1	GV130-8	1	线箱	Accessory box
2	GF109-8	3	机针	Needle (size #14)
3	GM172-8	1	拉链缝压脚组件	Zipper foot
4	GM107/4-8	1	扣眼压脚	Presser foot (spring hinged) comp. (for button holing)
5		1	平缝压脚部件	Presser foot (spring hinged) comp. (for straight stitching)
			Thread unwinder spool cap	17 GR790-8 2 双线团座
			Thread unwinder spool net	18 GR760/25-8 1 双线团架组件
			Thread unwinder compite (for two spools)	19 GR1397-8 1 大油盘
			Drip pan	20 膝提组件
			Control lever components	
			Tip screw	21 GS352-8 1 节头螺钉
			Hand wheel (for treadle operation)	22 GP142-8 2 机头连接钉
			Machine hinge	23 GR696/2-8 2 连接钉座
			Oil pan seat	24 GR687-8 2 油盘支座
			Oil pan seat nail	25 GBX141-8 2 操纵杆节头
			Control laever tip	26 GR695-8 1 操纵杆垫
			Control lever chshion	27 GR694-8 1 操纵杆垫
			Control plate	28 GR693-8 1 操纵板软垫
			Control lever	29 GR692-8 1 操纵板
			Control lever tip screw of pressure lift	30 GR691-8 1 操纵杆
			Position adjusting nut of two-way crank	31 GS358-8 2 操纵杆节头螺钉
			Open retaining ring of pressure lift shaft	32 GL170-8 1 双向曲柄限位调节螺母
			Twisting lpring of two-way crank	33 GR688-8 1 抱压脚轴开口挡圈
			Tow-way crank screw	34 GW196-8 1 双向曲柄扭簧
			Position adjusting screw of two-way crank	35 GS357-8 1 双向曲柄限位调节螺钉
			Tow-way crank scrank	36 GS356-8 1 双向曲柄螺钉
			Position adjusting nut of two-way crank	37 GL170-8 1 双向曲柄限位调节螺母
			Position adjusting screw of two-way crank	38 GS357-8 1 双向曲柄限位调节螺钉



序号 NO.	型号 PART NO.	数量 QTY	名 称	DESCRIPTION
39	GK197-8	1	抬压脚双向曲柄	Two-way crank of pressure lift
40	GZ270-8	1	抬压脚轴	Pressr lift shaft
41	54754	1	放油螺钉垫	Oil reservoir drain pulg screw gasket
42	454036-819	1	放油螺钉	Oil reservoir drain pulg screw
43	368377	1	油盘座垫	Oil pan seat cushion
44	GX305-8	2	抬压脚顶销杆	Top pin of presser lift
45	368377	4	机夹座垫	Machine head cushion
46	GR686-8	1	油盘垫	Oil pan seat cushion

## ACCESSORIES AND ATTACHMENT



序号 NO.	型号 PART NO.	数量 QTY	名 称	DESCRIPTION
1		1	防护罩组件	Belt guard comp.
2	GR2331-8	1	上轮罩壳	Belt guard (upper)
3	GR2330-8	1	上轮后罩壳	Belt guard (upper) cover
4	GS3342-8	1	防护罩在螺钉	Belt guard (upper) screw
5	GS3343-8	2	防护罩小螺钉	Belt guard (upper) screw
6	GO2332-8	2	防护罩小螺钉垫片	Belt guard (upper) screw washer
7	GS3344-8	1	支承螺钉	Belt guard (upper) screw stud
8	GR2332-7	1	皮带后罩	Belt guard (lower)
9	GBS204-8	2	皮带后罩安装螺钉	Belt guard (lower) wood screw
10	GBR210-8	2	皮带后罩螺钉垫片	Belt guard (lower) wood screw washer
11	FM105-8	1	包边挡板	Cloth guide
12	GS665-8	1	包边挡板螺钉	Cloth guide thumb screw
13	GR1000-8	1	保针架	Finger guard



IvLD8k+yK5rrLqovNaXQP069947Ijifjwzdee1FGHuVt0BC7/pKbGjMCcsb8+hnX3lhKnDlVMxaX  
BCuy21Ert6OhPoY2ysHCERBwj6aYddWK0CTQbUJUGBWOC58JgkdoFbYKAlghYHYHQRzlgkR1Iilpv  
dhhc/OSlq165qhWqy10fKsW79HbiEg5/3YBjXZj4M/83jNbyyXHLvBHzcOah3BfzeS1NsjsnSHD2n  
qFloz+0TNxr6ct/Rv+3XR3QXp17si/hX61daVnk7clflX555XeYur97iH06MDWV5wovr7S53eL5v  
vv8Z3zN+vefX47/Sd6X/D74/+MWQLs+Q7cv2VxrC/kZdo6HOV+v/kaHdv8mw2bFD00/bo9tr2OdL  
0+q0BtEn+10618Huk3x+nYEnjsVOxSWHu5yky7nbSZ2HaTuk44L17kpPOkKvsHJwAfO4ymy3HC4i  
CmkirWQnGcBodhS9wV95xVlp4glfKd1fpZwEIEs5gg7GqWcoHsqxnmqImaGslNzhmK0PBdBB9Z  
OHmyFzYPAP5stL4WdK14vZ8OrUfXOtGjWl+Sr/czdFS2sNAM6SF9qI/OzJmoj+OT/E+xtEofggcZ  
115B/4ml44rRumQLZU61Yys7iO8dbHOUKlzMkqrVP3umSeStG3FN1033VDMK0M9zjbU+hr8e3QP  
+3TQEmFhVA+GGAHVcaL95ggfZs+1Mu8Qkp7UZnXYeTR6q8hjNHohkd27t99y63kXhUf+2rp962cP  
E4wXpPiJtCuuuHJ2Yf40Enltw40JeDr+Sfxt8vuMW6/fND88090ydcbiTU90P7fyb7809Cww81WG  
A4Urlx27Yct7awj70ge2o2e7A23ZCBnwU3kPfkUUp1RWpJ+fTi2LxcW6xfBfZkjG15JYxs8wzEgr  
S6/nGw2NafXpd0j3aHX6VAw5wM0iL0FiYYmSlpJiBJ3Dq3F3Z5Es0xS0eiOLTvWkG7axXcusTvqO  
nqo54xNVfz4Tj1WxgIydATUkw4gsZaW4UrfSvtLZkSG0YEimngt0AxaMy/Hw59jSUD9ng7LtxHV  
7N14fGLk0kHF3p69qeXqala1XyccnjhlR/zD+H/HT8XfvTRYp837xbzu3Y8eeuCN7K4pwrWb0Kvn  
0WeVudEs+jU5DrPDI7f1butdOXfmaSVrg5VajhhGUl/yfuD/yvCFT5xiuNjQbrgz5S7LXt+IXgrx  
K911wVw+FchtlU3W63xXZ2srgvViQ8qFhnnGBu8sPBnZQcEKfZmX2UFZtiTqBLPW6zTk6H0+n1/K  
9in5vfqNlk22y6ZsyLvedk3evbY78w74DvgN28gtjhud9+Q9nBfNFxleu+Llh+1KhifssZP3McIv  
1XibArcEaEBxZoYDbubcFQf6oaZ8UpRPCvNJfpa3yERMpcSrhjBGbbXKUSTphbQG9EKhjcnNsN75F  
slU9+WTsj+9L4+x1IDQ0k8ZcJhIiRjsJ+sq9Dd5FJOJYQTOcXxAdcVDe7fXR3DSDNua61+L5bchN  
aXITd0OaVD3Rgj/sTesMtfSks6P3K3y7x6sqydmZG8rKZuWxIU92suxiVxm6qntMrDGQcl+D727D  
Hb7nfW/6RK9Pb+B5N1vHQYzeoJR51SFHQTWZDHTUsi8QVr1NphuJN5L0N3wrvqqdIhwQk+p9eFuy  
zY6SGG7PAZ4s5U/xlc3BrmDX9lKHgv06FozUoZRVhB3spnYogSmYYL9Gh0e9FhNhxW4F37aMbtLk  
Trjp3OJVB6Q+J0OseJpdksl1UhmThiN50/Xg08ICMnYvtvqJoUyzVxlXmUA+fHjJU6q36Span6ZkP  
+mJwpVIN0Qj18dAkVQleFwH0JdmqN8E78xxn4MDOEM9OEXFB0pevgwhYbbFjj1265d0P3n0Zn/6l  
eWlZV5GcESTFRJpPf/bOBCKMLbg4N6NQtlNnjTMX39N/9OYbimf08tj9WbaMlRc2Xnfb6Z4ivQY  
sbXiW2sKuVu5IVd6mad3SyPkPfKWdMogaCQ37xRzxQqYprARMhPyAZJFyQhQZxMlxrIhdLdKV+J  
X0naAB+U8nRhfrqulp+re47XXKRbxEd0K/hlucJkCt0d/C7ps04t/j3dtzoDx0uSVmfn2T5PV8pX  
6xp4rY136abr5urW6PbyT/Kv6L7gtDjW4tSQxumhxMnhmwOxscUm94cJrxO4oGqTANaDcdhy6Ep  
BeEERlhWMdqwzlyYaq2UagUxJWwy+VQKYVnFgc0pQRCsAlloCBwVNVptCgjDdF1MLNUiU1I07fMM  
uwljBs7AsWpamsKqLaeSrw7s/ukhXf88voG51DDKy4FXHMwi1JzUJh848ZkuzAlFOoJbb/i+e1T  
nZ05M19dOQgTh/OgTt261QXGKInqT8w0Wnp6lhwLbLITUvzYspxer1lfiV5wdEXyYXxu8mO+N4T  
711/5eLvkey4duJ1Mjv+JPONA+Lz6WqMO0zQoKtMGLdyVKMloDWBXR0M+NgfwWIK9A5Fp/27/j6Z  
L8JDM0x3DZ1/sYZ9L9UyPnF63IR+vdqEi1BfFv1BwmZKK68opdRmtTjstP2ZewaWL75mdMeq88r8  
8fkfkr99TLyEjh2LvX7/wV8fiu+7byW7oRYnPuRthVFIRb3drjRu1F2v20sekR7R7k19UvuyVrPY  
HLFH3Is9q8yr7avdgzyaSloplmlvLDbPpbLFe22DYq/0VfUV8Xvu84R360/FN7ZsGs8kpY3zCnEPA  
Yg8792gMHmOhkRoVLBN3qJB5Yh76MbFfeiLF5X3j2bnfHXzRo351EOphxYFyFLS2kxGE3myQ8WGA2  
VZQ7fBiImk3q1V5RbjYFg7TkrY237Lz8rbfjX2Na2mTPDM8rTTJh9O4D8aXxlkO7yGyyh/zs0K6P  
axati+PzjFKZaClerVszmJMRJ3FhGJmt2Og0DCaDLPpPGpKLX3VZMhCaMwHVC8aLiYzDSOKKf8i+  
WlwkXhCP4V6msL8BghDMgJgy15PR1UEy3srMsmZmZmXgMORluwJ52cUZfpPTvu86GRmaIr2pOlz  
501PFkfgPNN59DX854IqORUkwSXh/RiRnsJLZolR9shUhiZaJRNEcgoD8SXW/aAnp/B1Ysk8WMru  
/Ko5tWcm2NLzBaOWycxcfaF7cww7honZfeFJTD8R9shUhiZaJRNEcgoD8SXW/aAnp/B1Ysk8WMru  
/65h3I355Sv6X9sjjd9zzOKPfev35BS5ZdhXku7yk6jhn+GX86cd33fVdo9OLjZjyTS88dexFpJdv  
Kc7OLr711qJAdvHXH4op31z2w1NPvfdiU0+9pFbdojaze1OLJ02RT8xsxZ1Dc3Sr6CrdXXQv32cq  
aTUmWB+LiZ0dAG3y7BzQ/F24T89OjeVHtezUjE+cPFfQpM3kysKUK7VbbFaJcvUL66ZnrNzx9F17  
ZzU+Pp8fe+qr9zf81TxMcn8bz/rq9c/ip+PfyO8i8zL40MokiZUQ4f8ENyEtoI+Ah++FGsziI5+N  
7bcLi+FCLG/HchGSHmXWIF/M2qRMiGC5FqlRqZ55XtWM6ZXT8I2rtKS4qHBqQX4ob0puTjCQ7fd5  
ZU9WZka62+Vkt0waRmnGVIM+RafVSKKA7+z4Z1/vb2iVo8HWKB/0X3BBASv727Ci7XsVrVEZgxro  
1YnKDIfsXEkFJVF+g6SS1FTOSHKTAXVVBflyv+OvlrNR0u9Z84z5m+q80fk6Lian6Pmd6p5A+a9  
XgTI9c7VdXKUtmr10YbLVvfxT92hd4Mpulp/bbuu1B8GdSmYTeFclOHvHiSOmUTNUEf99EEKGgNO  
Kur219VHXf46NoMoF6hvWxftmt9cX5fu9UYK8qOkdr1/WRTYL41CggjUqsNExdqopA4jd7DVwA3y  
YP5o/43DJ1jWgtKv8K9oW9Ic5doibAxxCMetjzo2n3R+V8TOLbXN27/fms711zs7ZFbs798uR0fn  
N3+/1cvSSAT7QCwNNT2N+DQN6ISG91vFaP02khzlFyLQ8psJWxVyfu1f8sWaP2RHNX6Z/1X9/+o  
FbfG3R+FB2u8MbdbGUMgbte71/U7PdGq9P9kba6jEEr9C/YNORSZNe5LQX5gyZzUrGDqcbJjN7w  
/Uz72TYlp4qzXOOCs5olbEb+2WgQUXm5jDNP9uOaprGkfrR0L5+GYvhECKKik3BHOqLa2tZ+03RW  
z/BRiWdy/2fAlqAf/zTc2vaJmVegOlzYfLmJ2dNDdvP5KOHUDQvJ5mIVit7InOcqZbLcVivG6bl  
/m6TjAZvB02o27bi9EJUv9fLNVyGYQWYSG6bX5zsizDsvYQKIWhSJS2spbrMy22iinLjtMtZ+Gt  
frTKA6o/sEU1wbM/RpM9xX719Cix/y/N7cn2xoX+xvmXNMv1/a2Tum1cdE4p2c4UmmybEXTapu5  
dDqZo+mc2opGueSeMCs066N8AH9E1ahXRDk0SrWCyAlRU+sFyTSi83r/JWZY0nwPhHEfQ6ns09jk  
LKPTQ+eWZ5xTPmd2+n4058sHaeOis/r7dee0NaAD6u9v8MsN/a39bcOJbcv8ssnfP4Lufm9/d33r  
mQ0dThy+IT3acGMEF7GaTEdjptBr0E+unz+okOsXXtI8YgKQr1/UHMOrvrZ1VmQwG9uaR2QARa21  
Z2tZSWY1aCRo6DGqUZvSRsASabWorrlao5eXDBNS6pBDWEVg+TJN1JrUOnwJ2TbAvp5gP6NhfmyHP  
x7CCZ1G9+sgQgFyYAlMx1JgPC2ERTMEyaIel0AW90AcbyGmMiSn770sToIk/Jf6a+Cjx18TJxB8S  
Q4mRxBHEw41HEz9P7E7clbgvcXtiz+KuyYvs333YX7Lgk8iB357bMPnYmJ7i8JVPwDdZiWiIfT9e  
U4ieGEGqMeILOZ1YSBqxEhuxS1M7u/pWtK8UpnZuWlVw1NnVua5t/ZgOz1Xr2/s2r08UervblreL  
7RuXr21bp+nZONXXvmLZW13nhnXL2t2f3dqqzFFd0rV3bt17qbl+/vL2zT9u2DnO9b20rU1ThXuxp  
bbu2u219e+fa9pV9OjW3vmPV6j5NW29f+/q03jV899oNvcLyrnXr2sTVm7pXt3eK2EdHlwghd21b